

Tengely adatváltozatok

Sorszám	L	L1	L2	L3	H1	H2	M	D1	D2	D3
1.	185	35	48	12	50	25	M16	50	26	13
2.	152	25	45	6	50	18	M14	50	24	12
3.	155	28	51	10	55	20	M16	55	25	13
4.	165	31	55	10	60	25	M16	60	30	14
5.	172	27	59	12	36	20	M20	35	26	16
6.	175	31	47	5	40	22	M22	40	27	18
7.	180	33	52	10	46	30	M24	45	35	19
8.	190	26	57	7	50	21	M18	50	28	14
9.	190	29	49	13	60	25	M22	60	32	16
10.	195	32	53	10	55	27	M22	55	34	18
11.	205	28	48	9	65	24	M24	65	31	19
12.	150	33	60	10	54	25	M26	53	33	21
13.	165	55	40	20	42	18	M18	41	22	16
14.	158	55	35	25	40	17	M18	43	20	16
15.	150	55	45	15	44	21	M18	43	24	16
16.	150	35	50	10	44	21	M20	43	24	18
17.	152	40	30	10	42	20	M20	41	22	18
18.	185	33	47	14	50	25	M18	55	26	13
19.	150	30	45	8	50	18	M14	55	24	12
20.	155	30	50	10	55	22	M16	60	25	13
21.	165	33	55	8	60	25	M18	65	30	14
22.	170	27	60	12	36	22	M20	40	26	16
23.	154	28	55	12	46	21	M20	55	31	21
24.	160	32	35	8	50	30	M22	53	30	18
25.	175	32	40	8	50	21	M24	41	26	20
26.	180	38	45	10	55	25	M18	43	27	14
27.	192	36	50	12	60	27	M20	43	35	16
28.	200	38	55	18	36	25	M22	43	28	18
29.	210	40	60	18	40	21	M24	41	32	19
30.	150	28	50	8	60	20	M16	55	28	18
31.	155	33	30	12	36	21	M18	53	30	20
32.	165	27	50	12	46	30	M20	41	35	14
33.	170	28	47	6	50	21	M20	43	28	16
34.	166	35	50	10	36	20	M20	43	26	16
35.	155	36	55	12	42	21	M22	42	27	18